

Label ID

See Label ID on page 153 for more information on setting this feature.

START / END	
PROGRAMMING bar codes Label ID Position	
	Label ID Transmission: Disable
Label ID Position: Before Bar Code Data DEFAULT	
	Label ID Position: After Bar Code Data
Set UPC-A Label ID Character(s)	
	DEFAULT SETTING FOR THIS FEATURE: A (41 hex)
	Set UPC-A w/P2 Addon Label ID Character(s)
DEFAULT SETTING FOR THIS FEATURE: A (41 hex)	
Set UPC-A w/P5 Addon Label ID Character(s)	
	DEFAULT SETTING FOR THIS FEATURE: A (41 hex)
	Set UPC-A w/C128 Addon Label ID Character(s)
DEFAULT SETTING FOR THIS FEATURE: A (41 hex)	
Set UPC-E Label ID Character(s)	
	DEFAULT SETTING FOR THIS FEATURE: E (45 hex)